







6 Align the center of C-1 and A-8 and adjust the mounting position of A-10.

Alignez le centre de C-1 et A-8 et ajustez les positions de fixation de A-10.

Alinee el centro de C-1 y A-8 y ajuste la posición de colocación de A-10.



Failure to tighten screw A-10 completely will cause moving sideways of C-1.

Ne pas serrer complètement la vis A-10 entraînera un déplacement latéral de C-1.

Si no aprieta completamente el tornillo A-10, se producirá un desplazamiento lateral de C-1.